




SCREW-BRACKET ERSATZHALTERUNG/
SPARE SCREW-BRACKET MOUNT



SILIKON-ERSATZHALTERUNG (OPTIONAL)/
SILICONE BRACKET (OPTIONAL)



2 x click = on / power

+ 1 x click = standard


+ 1 x click = eco

+ 1 x click = flashing

+ 1 x click = fast-flashing

+ 1 x click = SOS flashing

+ 1 x click 5 sec. = off



Battery status


> 71%

70-31%

< 30%



Ladevorgang
Charging
Charge



Micro
USB

Micro USB cable incl.

[charger
not incl.]

Achten Sie bitte darauf, dass die rotmarkierte Abdichtung stets korrekt verschlossen ist. / Please always keep the silicone plug closed after charging.

Art.-Nr. 17530



HELMHALTERUNGS-SET
HELMET BRACKET SET

Art.-Nr. 20501



USB-LADEGERÄT
USB CHARGER

Art.-Nr. 00460



SCREW-BRACKET ERSATZHALTERUNG
SPARE SCREW-BRACKET MOUNT

Art.-Nr. 00145



SILIKON-ERSATZHALTERUNG
SILICONE BRACKET

SIGMA
GERMANY



USB
CHARGING

BUSTER 600

SIGMA-ELEKTRO GmbH

Dr.-Julius-Leber-Straße 15
D-67433 Neustadt / Weinstraße

SIGMA SPORT USA

3487 Swenson Ave.
St. Charles, IL 60174, U.S.A.

SIGMA SPORT ASIA

4F, No.192, Zhonggong 2nd Rd.,
Xitun Dist., Taichung City 407, Taiwan

